

# Agitator/Aspirator

(Part Nos. A5–A6)



Thank you for purchasing this fine product from Aquatic Eco-Systems, Inc. The agitator or aspirator you have selected will provide years of excellent service. Inspect your item and accompanying components upon receipt for physical damage and completeness. Call Pentair AES if the shipping container appears undamaged but parts are missing. Contact the shipper if parts have been damaged in shipment and parts are missing.



## **Electrical Shock Hazard**

Always take care when using electricity around water. To prevent water from running down the electrical cord of an aquarium device and reaching an outlet, always use a drip loop. Be sure the power cord extends below the outlet. To prevent water from entering an air pump that does not have backup power, always place the pump in a location above the aquarium waterline.

The agitator or aspirator that you have purchased is a 12VDC unit that is normally suspended above the water by its hanging ring. This heavy-duty unit comes with automatic thermal overload protection and an 8' power cord.



AQUATIC ECO-SYSTEMS™

---

2395 Apopka Blvd. • Apopka, FL 32703 • Phone: 877-347-4788 • Fax: 407-886-6787 • PAES.General@Pentair.com • PentairAES.com

# Agitator/Aspirator

(Part Nos. A5–A6)



Thank you for purchasing this fine product from Aquatic Eco-Systems, Inc. The agitator or aspirator you have selected will provide years of excellent service. Inspect your item and accompanying components upon receipt for physical damage and completeness. Call Pentair AES if the shipping container appears undamaged but parts are missing. Contact the shipper if parts have been damaged in shipment and parts are missing.



## **Electrical Shock Hazard**

Always take care when using electricity around water. To prevent water from running down the electrical cord of an aquarium device and reaching an outlet, always use a drip loop. Be sure the power cord extends below the outlet. To prevent water from entering an air pump that does not have backup power, always place the pump in a location above the aquarium waterline.

The agitator or aspirator that you have purchased is a 12VDC unit that is normally suspended above the water by its hanging ring. This heavy-duty unit comes with automatic thermal overload protection and an 8' power cord.



AQUATIC ECO-SYSTEMS™

---

2395 Apopka Blvd. • Apopka, FL 32703 • Phone: 877-347-4788 • Fax: 407-886-6787 • PAES.General@Pentair.com • PentairAES.com