



AQUATIC ECO-SYSTEMS™

ADJUSTABLE SCREW-STYLE AUGER FEEDER WITH SPREADER (PART NO. FS4050A)

This unit can be used with the following hoppers:

- FH22** – 22-lb hopper (10 kg)
- FH44** – 44-lb hopper (20 kg)
- FH88** – 88-lb hopper (40 kg)
- FH132** – 132-lb hopper (60 kg)

The Screw Style Auger Feeder with Spreader will give excellent service for many years. The two rheostats allow adjustment of the speed and duration of feed delivery. One controls the speed of rotation of the spreader and one controls the speed of the screw style auger.

Inspect the system components upon receipt for:

1. Physical damage.
2. Completeness:
 - a. Screw-style auger feeder assembly.
 - b. Power connector for 12VDC power supply.

Call AES if shipping container appears undamaged and parts are missing. Call the shipper if parts have been damaged in shipment or if container appears to have been opened during shipment and parts are missing.

ASSEMBLY:

1. Attach power connector to feeder.
2. Attach 12VDC power supply to power connector (use part no. **PA15**).

NOTE: Screw feeders draw .05 amps

